

## Network Connection Certificate For Sungard DS2000 PEI RiF Version B12.194.2.0 Radio connected dispatcher for use with Motorola MTM800E fixed mounted mobile radio running software version MR 5.9.1

The following equipment has been tested for connection to the Airwave network (the "Equipment"). The Equipment has been tested on the Airwave Reference System Rugby.

	Manufacturer/Customer:	Versions:	Other relevant details:	Date(s) Certificate issued:
Supplier	Sungard Public	Product Designation:-	Test Date:	Issued:
and Equipment Information	Sector Marshfield, Chippenham,	DS2000 B12.194.2.0 PEI RiF	17 Nov 10	19 Nov 10
	Wiltshire	Build versions:-		
	SN14 8SR	Rif B12.194.2.0		
		TETRA Terminal		
		Motorola MTM800 v5.9.1		

At the time the Equipment was tested the Airwave Network Reference System was configured as follows:

Airwave interface Software version	Airwave System was built to baseline	
Centracom Q303	R6.2_005.12	

The testing conducted on the Equipment suggests that it will not adversely impact the Airwave Network (as it had been configured in accordance with the above specifications). The testing was limited to terminal conformance in accordance with the latest specification and hence no specific data application functionality or performance of the product was exercised unless specified below or in the test results.

## **Notes/Observations:**

 This certificate applies only to a radio connected dispatch solution where the DS2000 RiF is connected directly to a Motorola MTM800E mobile terminal operating with version MR 5.9.1 software.

Date : 19 November 2010

- 2. If the originating radio terminal is configured to deliver status messages in time stamped SDS format then both status and emergency indications are delivered to the operator via the SDS gateway.
- The PEI RIF is not a fully integrated ICCS, and therefore has limited functionality. It does not support Ambience listening or patching. If multiple Rif connections are available then multiselect is supported.
- 4. The equipment presented for test had the TX timer set to 60 seconds. It is however recommended that this is reduced to 30 seconds to ensure that the dispatch radio does not continue to transmit longer than necessary should the link to the Rif fail.

## **Disclaimer:**

1. This conformance certificate does not indicate any security approval with respects to the operation of this hardware / software on the Airwave network.

It is the responsibility of the supplier and their customer (whether Airwave Solutions Ltd or 3rd party customer) to ensure the Airwave Accreditor's security requirements have been met before this hardware / software is deployed on the Airwave operational network. If this solution is deployed within the customer's security domain then the customers Accreditor / Senior officer responsible for security must give their approval inline with the Airwave Service Code of Connection.

2. The issuing of this Connection Certificate is for information purposes only and Airwave makes no warranty or guarantee whatsoever as to the fitness for purpose of the Equipment or its ability to operate correctly when connected to the Airwave Network or any other network or equipment. Your use of the Equipment, connection of the Equipment to the Airwave Network and reliance on the contents of this Connection Certificate (for whatever purpose) is at your sole risk. Airwave shall not be liable for loss or damages of any kind (whether due to negligence or otherwise) arising in relation to the Equipment, its connection to the Airwave Network and/or your reliance on the content of this Connection Certificate.

Issued by: Jayesh Patel. Head Of Airwave Ref Sys Email: <u>Jayesh.patel@airwavesolutions.co.uk</u>

Date : 19 November 2010